

# FLEMING'S RADNOR — LIVE ACT ADVANCE

555 E Lancaster Ave, Suite 10, Radnor, PA 19087

[Fleming's Prime Steakhouse & Wine Bar — Website / Google Maps](#)

**VERY IMPORTANT: Must carefully READ Audio Setup & Instructions below, and arrive extra early for your first shift for a proper sound check. The house system must be used as your primary audio source, and can be challenging to dial in.**

## MAIN CONTACTS

📞 Flight Emergency: 610-549-1506 (Call or Text) — if any issues

📞 Booking Management: Jon Schaffer 610-888-4777 • [jschaffer@flight-entertainment.com](mailto:jschaffer@flight-entertainment.com)

**Point of Contact:** Kris Herman (GM), Kristen Troncelliti, Pete Allison, Ellis or Manager on Duty

## VENUE OVERVIEW

Fleming's Prime Steakhouse & Wine Bar is a very upscale dining establishment in Radnor, PA, known for USDA Prime steaks, an extensive wine list, and five-star service. Located in Radnor's Financial Center along Philadelphia's Main Line, it's close to I-76 and I-476, and convenient to Valley Forge.

## PERFORMANCE OVERVIEW

**Performance Area:** Main Bar, set up on the back wall corner next to the kitchen area

**Performance Times:** 5:30PM–8:30PM

**Set Lengths:** (3) 50-minute sets with 10-minute breaks, or (2) 75-minute sets with a 30-minute break

**Music Format:**

- Upbeat and recognizable
- Pop, Top 40, Jazz & easy listening songs
- Vocal performances preferred but not mandatory
- Moderate dueling-style interaction with guests is expected and encouraged at this location

## IMPORTANT INSTRUCTIONS

- **PROPER ATTIRE:** must dress in business sharp attire — no exceptions
- Tip jars and signs are permitted but must be small and discreet
- Payments are processed through Flight Entertainment or your agency — not COD
- **SEE Audio Setup & Instructions below for use of house system**

## HOSPITALITY

- Food & Beverage: 50% off bar menu items for performers only
- Alcoholic beverages are prohibited for the duration of your time at the venue

---

## ARRIVAL & LOAD-IN — ARRIVE 60 MINUTES IN ADVANCE OF SCHEDULED TIME

---

### Load-In and Parking:

- Plenty of surface lot parking available
- Check in at the main entrance hostess stand, and enter through the main doors

---

## MARKETING & PROMOTIONS

---

- Do not create any event collateral using the likeness of Flemings brand on your own whatsoever
- Feel free to promote your events without any branded flyers, and capture & share live performance content
- Add performance dates to your website/calendar
- Please Tag & Follow: @flemingssteakhouse, @flightentgroup, @schaffersounddjs
- Add an authentic 5-star Google review about your experience at the venue

---

## AUDIO SETUP & INSTRUCTIONS

---

- **House System:** must be used as your primary audio — your own system is secondary
- **Set Up:** must be compact, safe, and presentable, with all wires neatly tucked
- **Backline:** bring your own instruments, mics, stands, and any cables needed to perform
- **Speaker:** bring one small speaker to use as a monitor and to cover sound in the small bar area
- **Mixer:** bring a mixer with line-level outputs, or use the mixer provided on site
- **Line Level Output:** most mixers convert Mic Level to Line Level; make sure your XLR feed is always coming from a line-level output into the wall jack
- **Please Note:** Do NOT plug any Mic Level XLR outputs directly, or from a self-powered monitor, into the wall jack
- **DI Box:** will convert Mic Level to Line Level output
- **Male XLR Cable:** run out of mixer to plug into Female XLR Wall Jack
- **Manager on Duty:** will turn your house feed live and assist setting proper sound levels

---

## HOUSE MIXER PROVIDED (OPTIONAL) — USE IF YOUR EQUIPMENT DOES NOT WORK

---

- **House Mixer:** Mackie Mix 5, provided and located in the closet next to the set-up area
- **Power:** Plug the AC power cord into the wall — the mixer will turn on automatically
- **Vocal Input:** Plug XLR mic cable into Channel 1
- **Piano / Instrument Input:** Plug 1/4" instrument cable into the top Bal/Unbal Channel 2/3
- **Gain Level:** Set gain between 6 o'clock and 9 o'clock
- **All Levels:** Set all levels at 12 o'clock as a general rule
- **House Output:** Plug 1/4" cable into Main Bal/Unbal Output on the mixer, into the XLR wall jack
- **Monitor Output:** Plug 1/4" cable into Main Out or Phones on the mixer, into the XLR monitor
- **Main Button:** Press "To Main" on the mixer for main output volume
- **Phone Button:** Press "To Phones" on the mixer for monitor output volume
- **Main Volume:** Adjust line levels on the mixer for the right volume levels
- **Monitor Volume:** Adjust volume levels on the self-powered speaker for the right volume levels

## TROUBLESHOOTING TIPS — EMERGENCY: 610-549-1506

---

- **Distortion:** system may distort at low volume, even though it sounds fine in your monitor
- **Mixer Gain Levels:** most distortion is caused by the Gain level on the mixer being too high — start at 9 o'clock and adjust down to 6 o'clock if needed
- **Mixer Line Levels:** start at 12 o'clock and increase to 3 o'clock, or as high as needed for the right volume, always keeping the LED lights in the green
- **Mixer Master Level:** generally, keep your master levels at 12 o'clock
- **Other Mixer Levels:** generally, set your Pan, EQ, and all other levels at 12 o'clock